

Quiz Board

Play & Learn – NOVO/YUVO Hydraulic

Model No.: QB-A01-R1

USER MANUAL

- ❖ Safety Rules for Working with Electrical Equipment 2
- ❖ Start-up Guide 3
- ❖ Playing with Quiz board 3

नोवो और योवो – नोवो / यूवो हाइड्रॉलिक

Play & Learn - NOVO / YUVO hydraulic

त्रुटि Problem	संभावित कारण Probable cause
<p>ऑपरेटर अपने आप नीचे आता है</p> <p style="color: red;">Automatic Lowering of implement</p> <p>पी.सी. लीवर द्वारा ऑपरेटर बहुत धीरे से ऊपर उठता है</p> <p style="color: red;">Slow Lifting of implement by PC Lever</p> <p>ऑपरेटर पी.सी. अथवा डी.सी. लीवर से नहीं उठता है</p> <p style="color: red;">Implement not Lifting by PC / DC Lever</p> <p>ऑपरेटर पूरा उठने के बाद झटके देता है (लेकिन इंगिन बंद करने पर ऑपरेटर नीचे नहीं आता)</p> <p style="color: red;">Implement jerks when lifted fully (but implement does not come down when engine is stopped)</p> <p>इंजिन बंद करने पर ऑपरेटर नीचे आता है / इंगिन चालू रहने पर झटके देता है</p> <p style="color: red;">Implement comes down when engine is stopped / jerking when engine is running</p>	<p>मुख्य विस्टन सील से रिसाव Leakage from main piston seal</p> <p>हाइड्रॉलिक सिलिंडर और हाइड्रॉलिक हाउसिंग के बीच 'ओ' रिंग से रिसाव Leakage from 'O' ring between hydraulic cylinder and hydraulic housing</p> <p>शॉक लोड रिलीफ वाल्व (एस.एल.आर.वी.) सीट से रिसाव Leakage from Shock Load Relief Valve (SLRV) seat</p> <p>लोअरिंग स्पूल सीट से रिसाव Leakage from lowering spool seat</p> <p>'लोअरिंग स्पूल कंट्रोल वाल्व' सीट से रिसाव Leakage from 'Lowering Speed Control Valve' seat (optional)</p> <p>नॉन रिटर्न वाल्व (एन.आर.वी.) सीट से रिसाव Leakage from Non Return Valve (NRV) seat</p> <p>ऑपरेटिंग प्लग वाशर से रिसाव Leakage from auxiliary plug washer</p> <p>कंट्रोल वाल्व असेंबली और हाइड्रॉलिक हाउसिंग के बीच 'ओ' रिंग से रिसाव Leakage from 'O' ring between control valve assembly & hydraulic housing</p> <p>ओयल का स्तर कम होना Low oil level</p> <p>सूखन फिल्टर या स्ट्रेनर में रुकावट Suction filter or strainer choked</p> <p>रेगुलेटिंग विस्टन वाल्व बॉल सीट से रिसाव Leakage from regulating piston valve ball seat</p> <p>कॉम्पेन्सेटर असेंबली ठीक से काम न करना पूर्ण खुली स्थिति में कॉम्पेन्सेटर खंडित Faulty compensator valve- not operating or stuck at one position</p> <p>मुख्य 'डिबंद राहत (रिलीफ) वाल्व' सीट से रिसाव Leakage from main relief valve seat</p> <p>प्रणाली पर अधिक भार डालना Higher load of lifting</p> <p>आइसोलेटर वाल्व 'ओ' रिंग से रिसाव Leakage from isolator valve 'O' ring</p>

शक्ति

POWER

द्वारा शुरू करना

RESET

महिन्द्रा ऐक्स.लंस सेंटर – नागपुर, मोहाली और जहीराबाद

SAFETY RULES FOR WORKING WITH ELECTRICAL EQUIPMENT

A safe work environment is not always enough to control all potential electrical hazards. You must be very cautious and work safely.



- Do plug power equipment into wall receptacles with power switches in the OFF position.
- Do plug electrical equipment in OFF condition.
- Do unplug electrical equipment by grasping the plug and then pulling.
- Disconnect the power source before servicing or repairing electrical equipment.
- Stay away from exposed electrical parts unless you are a qualified worker.
- Keep the work area clean.
- Leave electrical repairs to qualified personnel.



- Do not plug power equipment into wall receptacles with power switches in the ON position.
- Do not unplug electrical equipment in ON condition.
- Do not plug equipment into defective receptacles.
- Do not pull or jerk the cord to unplug the equipment.
- Do not touch equipment or electrical devices unless instructed to do so.
- Don't place cords near heat or water.
- Don't touch anything electric with wet hands.

START-UP GUIDE

Checking the Contents

Sr. No.	Name	Type / Rating	Quantity
1.	Quiz Board		1 unit
2.	Mains cord		1 unit
3.	User Manual		1 unit

PLAYING WITH QUIZ BOARD

- Insert Mains cord into Auxiliary socket.
Insert 3-pin plug into AC outlet socket.
Earthing must be proper. If not, risk of electric shock.
- Switch on Power switch.
Power ON Indicator will glow.
- To select desired Question, press alongside switch momentarily.
Green LED glows which indicates that particular Question is selected.
- To select another Question, press alongside switch of that question.
- To de-select / re-select / repeat that question, press Reset switch momentarily.
- Blue LED indicates the maximum possible answers of that question.
- Now choose the possible answers by pressing respective switches.
If Answer is correct, Green LED glows.
If Answer is wrong, Red LED glows.
- For each Answer selection, the Blue LED goes Off.
- If all possible answers are correct, then a recorded voice will say “Congratulations, you have selected all correct possible causes”
If one or more answers are wrong, then a recorded voice will say “Better luck next time”
- At any time, you can terminate the process by pressing Reset switch.